


Charging Battery with Motion Power Supply (not included)



Remove power supply from actuator motor (that came with your furniture)

Connect power supply to battery to charge as pictured above.

If needed, use the two adapter cable with barrel ends to adapt to different power supplies

Once fully charged, remove power supply and connect battery to actuator motor

